



**KW automotive  
North America, Inc.**  
1075, North Avenue  
Sanger, California 93657  
phone: 559.875.0222  
fax: 559.876.2259  
info@KWautomotive.com  
www.KWautomotive.com

## Product Comparison

### Belltech 6400/6401 Shackle

Some of you may have noticed new shackle part number 6401 listed in the 2008 Belltech application guide for the new body style 2007+ GM ½ ton trucks. Knowing that the old shackle part number 6400 fits both the 99-06 GM trucks and the new body style 2007+ GM trucks why would we list a different part number?

The 6400 shackle kit and the 6401 shackle kit both have the same exact shackles in the box but the 6401 shackle kit also includes a spacer hardware kit. The new body style 2007+ 2WD/4WD GM ½ ton trucks come from the factory with a 1" lifting block between the axle and the leaf spring but if you remove this factory block, the factory u-bolts do not have enough thread on them to tighten them back up so we have included spacers to compensate for this. This will give the installer the option to do a 2" shackle drop or do a 3" drop using the shackle and removing the factory block. The great thing about the 6401 shackle kit is that it is the same price as the 6400 kit yet it gives the customer the option of 1" more of lowering. Some of new Silverado trucks that we worked on in R&D had well over 3" of rake from front to rear and we felt 3" of rear drop would help level the trucks out better.



TOP SPACER BLOCK



NEW SPACERS